THE DEPICTED DETAIL SHOWS ONE OF THE SEVERAL COMMONLY ACCEPTED METHODS OF WINDOW INSTALLATION. **BLUESKIN VP100 BLUESKIN VP100** (100MM) HENRY -SELF-ADHERED OR **HENRY LIQUID** HENRY SELF-ADHERED APPLIED FLASHING **FLASHING** APPLY A 3/8" -(10MM) BEAD OF **INSTALL WINDOW MOISTOP SEALANT** PER WINDOW ON INTERIOR SIDE **MANUFACTURER** 4" (100MM) OF WINDOW FLANGE REQUIREMENTS (INTERMITTENTLY ON SILL FLANGE TO ALLOW FOR HENRY SELF-ADHERED DRAINAGE) **BOW TIE FLASHING** INTERIOR AIR -AND WATER SEAL HENRY -**SELF-ADHERED** (50MM) HENRY -**FLASHING SELF-ADHERED** OR HENRY LIQUID APPLIED (50MM) **FLASHING BLUESKIN VP100** WINDOW FLASHING **ASTM E2112 - METHOD B1** ISOMETRIC VIEW SECTION VIEW



HENRY 1-2-3 MOISTURE CONTROL SYSTEM WEATHER-RESISTIVE BARRIER (WRB) INSTALLATION GUIDELINES

NOTES

- VISIT WWW.HENRY.COM/WARRANTY FOR ELIGIBILITY REQUIREMENTS OF THE 15-YEAR RESIDENTIAL AND LIGHT COMMERCIAL HENRY 1-2-3 MOISTURE CONTROL SYSTEM WARRANTY.
- 2. HENRY OFFERS BLUESKIN VP100 IN THE UNITED STATES AND CANADA, PRODUCT AVAILABILITY AND WARRANTY OPTIONS MAY VARY BY LOCATION. REFER TO THE HENRY BLUESKIN VP100 GUIDE SPECIFICATION FOR RECOMMENDED FLASHINGS. SEALANTS, AND SYSTEM INFORMATION.
- 3. INSTALLATION "METHOD B1" REFERS TO COMMON WINDOWS (SURFACE MOUNTED). INSTALL WINDOW PER WINDOW MANUFACTURER REQUIREMENTS.
- 4. PROVIDE INTERIOR AIR AND WATER SEAL AT WINDOW PERIMETER PER WINDOW MANUFACTURER RECOMMENDATIONS.
- 5. SEE PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR ROLL SIZES, MAXIMUM UV EXPOSURE, COMPATIBILITY CONCERNS, APPLICATION TEMPERATURES AND SERVICE TEMPERATURE LIMITATIONS.
- 6. CLADDING, INSULATION, AND OPTIONAL INTERIOR VAPOR BARRIER NOT SHOWN FOR CLARITY, REFER TO LOCAL CODE ORDINANCES FOR INSULATION AND VAPOR BARRIER REQUIREMENTS.
- 7. SUBSTRATES MUST BE CLEAN AND DRY.
- 8. SELF-ADHERED MEMBRANES MAY REQUIRE A PRIMER FOR OPTIMAL ADHESION TO SOME SURFACES AND/OR SUBSTRATE TEMPERATURES. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR PRIMER REQUIREMENTS.
- 9. VERIFY WEATHER-RESISTIVE BARRIER IS FREE FROM PROTRUSIONS OR DAMAGE PRIOR TO CLADDING INSTALLATION.
- 10. CONTACT HENRY AT 800-773-4777 FOR TECHNICAL ASSISTANCE.



999 N. Pacific Coast Highway. Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com

BLUESKIN VP100 SELF-ADHERED AIR BARRIER

FLANGED WINDOW - METHOD B1

WINDOW INSTALLATION WITH PAN FLASHING AT SILL FLASHING INSTALLED BEFORE WRB

DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING, PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION. DETAILS ARE NOT TO SCALE. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR PRODUCT INFORMATION, RECOMMENDED AUXILIARY COMPONENTS AND INSTALLATION INSTRUCTIONS.

04-18-2022 PAGE 1 OF 1

VPWRB-6B1-P²