



Notes:

1. Refer to Henry Air-Bloc Guide Specification for transition strip requirements.
2. Always stop Blueskin TWF flashing membrane back from exterior face of veneer. Extend the drip edge using prepainted metal to suit.
3. Where gaps occur in exterior sheathing around brick ties, use HE925 BES or Air-Bloc LF to seal. Alternatively, use a strip of Blueskin extending 3" around tie and seal all edges with HE925 BES or Air-Bloc LF.

Henry
COMPANY®

VAPOR PERMEABLE AIR-BLOC MEMBRANE

SCALE: N.T.S.

BRICK VENEER/ STEEL STUD WALL

02-20-14

**SHELF ANGLE
DETAIL**

AB-H119