



Notes:

1. Refer to Henry Air-Bloc® Guide Specifications for transition membrane requirements.
2. Surfaces to receive Blueskin® transition membrane must be properly prepared and primed according to Henry documents.

Henry
COMPANY®

VAPOR PERMEABLE AIR-BLOC 33MR MEMBRANE

SCALE: N.T.S.

HORIZONTAL PIPE

09-30-13

**PENETRATION
DETAIL**

AB-H130