

NOTES:

- DETAIL SHOWS HENRY PRODEQ SYSTEM WATERPROOFING ASSEMBLY. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- 2. THE STANDARD PRIMER FOR THE HENRY **PRODEQ** SYSTEM IS **HENRY ST PRIMER** WITH AGGREGATE. OTHER RECOMMENDED PRIMERS INCLUDE: **HENRY LV PRIMER**, **HENRY STXL PRIMER** WITH AGGREGATE, **PUMADEQ PRIMER 20** WITH AGGREGATE AND **HENRY GC EPOXY PRIMER**. REFER TO PRODUCT SPECIFIC DATA SHEET FOR PRODUCT SPECIFIC INFORMATION.
- 3. FORM A COOL SLEEVE AROUND PIPES HOTTER THAN 150 °F (65 °C).
- 4. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" (50MM) BEYOND PRODEQ SYSTEM APPLICATION IN ACCORDANCE WITH HENRY PRODEQ SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- 5. DO NOT INSTALL **PRODEQ** SYSTEM BEYOND PRIMED SURFACES.
- 6. HENRY OFFERS PAVERS, RIGID INSULATION, AND PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 7. REFER TO PRODEQ SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



DRODEO OVOTEM WATERPROOFING ACCEMBLY

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PRODEQ SYSTEM - WATERPROOFING ASSEMBLY

PIPE PENETRATION

TYPICAL PRODEQ SYSTEM - PIPE PENETRATION ON A VERTICAL SUBSTRATE WITH TOP COAT

SCALE: N.T.S.

06-17-2022

PRODEQ-P2B

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com