



NOTES:

1. DETAIL SHOWS **HENRY® PUMADEC™** SYSTEM WATERPROOFING ASSEMBLY WITH A REINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
2. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEC™** SYSTEM APPLICATION IN ACCORDANCE WITH **HENRY® PUMADEC™** SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
3. DO NOT INSTALL **PUMADEC™** SYSTEM BEYOND PRIMED SURFACES.
4. BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEC™** RESIN.
5. **HENRY®** OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT **HENRY®** FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
6. REFER TO **PUMADEC™** SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.

Henry®

999 N. Pacific Coast Highway, Suite 800
El Segundo, CA 90245
800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. **HENRY®** DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEC™ SYSTEM - WATERPROOFING ASSEMBLY

CURB FLASHING

**REINFORCED FIELD MEMBRANE UPTURN FLASHING
AT DOOR THRESHOLD WITH TOP OR WEAR COAT**

SCALE: N.T.S.

04-26-2019

PUMADEC-C3H