



NOTES:

1. DETAIL SHOWS HENRY VEGETATIVE ROOFING WITH **PUMADEQ** SYSTEM WATERPROOFING ASSEMBLY WITH A REINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
2. DO NOT INSTALL **PUMADEQ** SYSTEM BEYOND PRIMED SURFACES.
3. BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEQ** RESIN.
4. PERMANENTLY SECURE DOWEL/REBAR PRIOR TO WATERPROOFING INSTALLATION TO PREVENT VERTICAL OR LATERAL MOVEMENT.
5. DOWL/REBAR MUST BE FREE FROM RUST, OIL AND CONTAMINANTS.
6. VERIFY WATER OUTLET, SUCH AS DRAINS AND/OR SCUPPERS, ARE LOCATED AT CONFINED SPACES TO AVOID PONDING WATER.
7. DEPTH OF GROWING MEDIA MAY VARY DEPENDING ON PROJECT SPECIFIC REQUIREMENTS.
8. DETAIL IS FOR REFERENCE ONLY. REFER TO DESIGN PROFESSIONAL TO VERIFY WIND UPLIFT REQUIREMENTS.
9. REFER TO THE **PUMADEQ** SYSTEM GUIDE SPECIFICATION AND WATERPROOFING DETAILS FOR RECOMMENDED INSTALLATION PROCEDURES.

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

VEGETATIVE ROOFING - PUMADEQ SYSTEM

DOWEL/REBAR
REINFORCED FIELD MEMBRANE (CSP 3-5)
TYPICAL PLANTER DETAIL

SCALE: N.T.S. 06-01-2020

VR-PUMA-R7C



999 N. Pacific Coast Hwy, Suite 800
 El Segundo, CA 90245
 800-486-1278 • www.henry.com