



Notes:

1. Blueskin SA should be used as a transition sheet on all Air-Bloc 06, 21, and 32 systems.
2. Typical application sequence is to install the Blueskin membrane first, followed by the Air-Bloc liquid membrane.
3. Where large gaps occur in exterior sheathing around brick ties, use Air-Bloc 21 to seal followed by reinforcing tape. Alternatively, use a strip of Blueskin SA extending 3 in. around tie and seal all edges with Air-Bloc 21.
4. Air-Bloc 21 can also be used as an adhesive to bond rigid insulation to exterior sheathing or other Air-Bloc systems.

Henry
COMPANY

AIR-BLOC 06, 21 OR 32

SCALE: N.T.S.

BRICK VENEER/ STEEL STUD WALL

FIT TO PAPER

**PARAPET
DETAIL**

AB-H101