



Notes:

1. Blueskin SA is self-sealing when self-taping fastening systems are used.
2. The transition membrane from the wall to the roof assembly should tie-in to the roof air/vapor barrier to ensure air seal continuity. Ensure compatibility.
3. It is recommended that a pre-start meeting be held between general contractor and subtrades to coordinate application of the membrane and transition membranes at wall-to-roof, wall-to-window and the junction of dissimilar materials, etc.
4. Apply Air-Bloc 21 to back of insulation panels in a serpentine pattern, and to insulation panel joints, to restrict air movement.
5. Apply Blueskin membranes in shingle fashion whenever possible.

**Henry**  
COMPANY®

BLUESKIN SA

SCALE: N.T.S.

BRICK VENEER/ CMU WALL

FIT TO PAPER

**PARAPET  
DETAIL**

**AB-H104**