



Notes:

1. Blueskin is self-sealing when self-taping fastening systems are used.
2. When Blueskin membranes are used for the air-vapor barrier, the brick tie system can be installed after the Blueskin is installed. This helps assure continuity and significantly reduces installation time.
3. Blueskin TWF is a self-adhering sheet used for thru-wall flashing applications. Blueskin TWF is to be applied to a prepared and primed substrate.
4. Always stop Blueskin TWF flashing membrane back from exterior face of veneer. Extend the drip edge using prepainted metal to suit.
5. An alternate detail for the thru-wall flashings includes extending the membrane across the top of the floor slab prior to installing the lower track.
6. Air-Bloc 21 may be used as an adhesive to bond rigid insulation to Blueskin SA or other Air-Bloc systems. Air-Bloc 21 is applied by notched trowel or gunned in a serpentine pattern to the back of the insulation panels to restrict air movement. Insulation panel joints are also buttered.

Henry
COMPANY

BLUESKIN SA

SCALE: N.T.S.

BRICK VENEER/ STEEL STUD WALL

FIT TO PAPER

**SHELF ANGLE
DETAIL**

AB-H107