



1. Deck
2. Aquatac Primer or Blueskin Adhesive
3. Blueskin WP 200 Membrane
4. HE925 or Polybitume
5. HE925 or Polybitume
6. Synko-Flex or Hydro-Flex Waterstop

Notes:

1. System detail showing typical application to a concrete foundation wall and deck.
2. Blueskin WP 200 must be protected. Use extruded polystyrene insulated assemblies. Prefabricated geocomposite drainage boards, polypropylene, or asphaltic protection board may also be used.

**Henry**  
COMPANY®

BLUESKIN WP-200

SCALE: N.T.S.

FOUNDATION WALL APPLICATIONS

**SYSTEM  
DETAIL**

**ES-H101**