



Notes:

1. A 9" reinforcing strip of Blueskin WP 200 is applied at 90 degree changes in plane.
2. Terminations in the membrane are sealed using Henry HE925 BES Sealant.
3. Use Aqua-Bloc 2P to smooth rough substrate at top of footing, where required.
4. See Technical Data Sheets for requirements of membrane protection.

Henry
 COMPANY
 www.henry.com

BLUESKIN WP-200

SELF-ADHERED WATERPROOFING SYSTEM

**WALL/FOOTING
 DETAIL**

SCALE: N.T.S.

09-16-10

ES-H103