



Notes

1. Termination detail may also be a reglet/counter flashing.
2. Seal all terminations with HE925 if not covered on same day by field membrane.
3. A termination bar must be used on all deck-to-wall expansion joint details.
4. See Technical Data Sheets for requirements of membrane protection.

Henry
COMPANY®

BLUESKIN WP-200

SCALE: N.T.S.

SELF-ADHERED WATERPROOFING SYSTEM

**EXPANSION
JOINT DETAIL**

ES-H108