



Notes:

1. This detail shows a standard application of a Neoprene Flashing Sheet.
2. Neoflash flashing sheet must be concealed to prevent UV exposure.

Henry
COMPANY

790-11 MEMBRANE P.M.R. ASSEMBLY

SCALE: N.T.S.

CONCRETE DECK - PARAPET

FIT TO PAPER

**NEOPRENE
FLASHING DETAIL**

HR-H105