



Notes:

1. An air/vapor barrier transition membrane, such as Blueskin, is installed prior to building the wood parapet. This ties the 790-11 membrane system into the wall air/vapor barrier to maintain continuity.
2. The joints in the gypsum board roof deck are treated with 4" Blueskin, prior to applying the 790-11 membrane system.

Henry
COMPANY®

790-11 MEMBRANE P.M.R. ASSEMBLY

SCALE: N.T.S.

STEEL DECK / PLYWOOD PARAPET

FIT TO PAPER

**NEOPRENE
FLASHING DETAIL**

HR-H109