



**Notes:**

1. The flashing sheet must be either modified PLUS NP180 s/s or Neoflash Flashing Sheet.
2. The flashing sheet is set in a 125 mils bed of 790-11 prior to installing the membrane in the field.
3. The first coat of 790-11 should be applied to a thickness of 90 mils min. prior to the application of the Polyester Fabric. the second coat is applied to a thickness of 125 mils min.

**Henry**  
COMPANY®

790-11 MEMBRANE P.M.R. ASSEMBLY

SCALE: N.T.S.

CONCRETE DECK - TRANSITION

FIT TO PAPER

**CONSTRUCTION  
JOINT DETAIL**

**HR-H113**