



- NOTES: 1. REFER TO THE HENRY PUMA TECHNICAL DATA SHEET FOR PRIMER SELECTION AND PROPER SUBSTRATE PREPARATION PRIOR TO INSTALLATION.
2. HENRY 790-11 OR CM100 WATERPROOFING MEMBRANE MAY BE USED AS THE *FIELD MEMBRANE* IN THE DEPICTED DETAIL. THE REQUIRED PROTECTION COURSE FOR THE DEPICTED *FIELD MEMBRANE* IS NOT SHOWN FOR CLARITY.
3. REFER TO THE HENRY 790-11 OR CM100 TECHNICAL DATA SHEET AND GUIDE SPECIFICATION FOR SURFACE PREPARATION AND APPLICATION INSTRUCTIONS SPECIFIC TO THE *FIELD MEMBRANE*.

Henry
COMPANY®

AQUA-BLOC PUMA LIQUID APPLIED FLASHING

SCALE: N.T.S.

CONCRETE DECK

03-17-17

PIPE PENETRATION
DETAIL

PUMA-3A