



Notes

1. Cant strips are not required when the cap sheet flashing or all plies are thermofused.
2. Beveled edges on poured concrete corners are recommended.
3. A drainage layer or channeled insulation panels may be used.
4. The base sheet may extend 1" up the vertical to provide temporary watertightness. Ensure edge is sealed.
5. The cap sheet flashing membrane must have a granular surface if it is exposed.
6. The termination detail may be as shown or as MB-3B97 or MB-4B97.

modifiedPLUS Roofing Systems

PARAPET DETAIL

P.M.R. ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 04

MB-15E97



Henry Company
 2911 Slauson Avenue, Huntington Park CA 90255
 (800) 486-1278 techservices@henry.com
<http://www.henry.com>