



Notes

1. Remove embedded gravel on cant strips prior to applying base sheet flashing.
2. When Re-Cover Board is adhered with hot asphalt or cold adhesive, the existing BUR should be wet-vacuumed rather than mechanically swept.
3. Primer is required over the existing BUR flashing prior to installing the base sheet flashing.
4. The base sheet may extend 1" up the vertical to provide temporary watertightness.
5. The metal flashing may be omitted if the granule surfaced cap sheet flashing membrane is carried over the parapet so that only the granular surface is exposed.

modifiedPLUS Roofing Systems

PARAPET DETAIL

RE-COVER ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 04

MB-18E97



Henry Company
 2911 Slauson Avenue, Huntington Park CA 90255
 (800) 486-1278 techservices@henry.com
<http://www.henry.com>