

NOTES:

- 1. DETAIL SHOWS HENRY **PRODEQ** SYSTEM WATERPROOFING ASSEMBLY. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- 2. THE STANDARD PRIMER FOR THE HENRY PRODEQ SYSTEM IS HENRY ST PRIMER WITH AGGREGATE. OTHER RECOMMENDED PRIMERS INCLUDE: HENRY LV PRIMER, HENRY STXL PRIMER WITH AGGREGATE, PUMADEQ PRIMER 20 WITH AGGREGATE AND HENRY GC EPOXY PRIMER. REFER TO PRODUCT SPECIFIC DATA SHEET FOR PRODUCT SPECIFIC INFORMATION.
- 3. FULLY BROADCAST, TO REJECTION, DRY SILICA SAND (SIEVE SIZE: #20-30) INTO WET HENRY GP WEARCOAT.
- 4. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" (50MM) BEYOND **PRODEQ** SYSTEM APPLICATION IN ACCORDANCE WITH HENRY **PRODEQ** SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- DO NOT INSTALL PRODEQ SYSTEM BEYOND PRIMED SURFACES.
- HENRY OFFERS PAVERS, RIGID INSULATION, AND PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 7. REFER TO PRODEQ SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR

PRODEQ SYSTEM - WATERPROOFING ASSEMBLY

CURB FLASHING

TYPICAL PRODEQ SYSTEM - UPTURN
FLASHING AT WINDOW SILL WITH TOP OR WEAR COAT

SCALE: N.T.S. 06-17-2022

PRODEQ-C4F

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com