

# Henry® Air Barrier Assemblies Meet ASTM E2357

To date, there are two industry-recognized methods of defining air permeance for air barriers.

Industry standard for determining air leakage	
Test type	Test Method
Individual product testing	ASTM E2178 - Standard Test Method for Air Permeance of Building Materials
Assembly testing	ASTM E2357 - Standard Test Method for Determining Air Leakage of Air Barrier Assemblies

### ASTM E2357 simulates an installed air barrier assembly

ASTM E2357 measures the air leakage of an “opaque” (non-penetrated) wall, and compares it with the air leakage of a wall containing pipe penetrations, brick ties, electrical boxes, foundation transitions, lap seams and a rough window opening; recording positive and negative air pressure, wind gust loads and sustained gust loads. If the measured air leakage rate of the penetrated wall is greater than 10% of the opaque wall, the system fails.

Henry® Company has a broad portfolio of assemblies meeting the definitive standard as shown below.

Henry® assemblies that meet ASTM E2357			
Henry® air barrier tested assembly	Air barrier assembly type	Assembly permeance	Status
Blueskin® SA Self-Adhered Water Resistive Air Barrier	Self-adhered	Non-permeable	Passed
Blueskin® VP160 Self-Adhered Water Resistive Air Barrier	Self-adhered	Vapor permeable	Passed
Air-Bloc® 16MR Air and Vapor Barrier	Fluid applied	Non-permeable	Passed
Air-Bloc® 17MR Vapor Permeable Air Barrier	Fluid applied	Vapor permeable	Passed
Air-Bloc® 31MR Vapor Permeable Air Barrier	Fluid applied	Vapor permeable	Passed
Air-Bloc® 32MR Air and Vapor Barrier	Fluid applied	Non-permeable	Passed
Air-Bloc® 33MR UV-Resistant, Vapor Permeable Air Barrier	Fluid applied	Vapor permeable	Passed

Henry, Blueskin and Air-Bloc are registered trademarks of Henry Company

Ask us today about other Henry® solutions that help manage the flow of water, air, vapor and energy.

**Building Envelope Systems®**  
Roofing | Air Barrier | Waterproofing